

FOUR-DOOR MOTOR CARS 1980-1989

Engine Menu

E1	Crankcase
E2	Crankcase covers and sump
E3	Crankshaft, damper and pulley
E4	Connecting rods and pistons
E5	Camshaft thrust plate and valves
E6	Cylinder heads
E7	Oil pump, pick-up and dipstick
E8	Oil filter and fittings
E9	Oil filter, breather and fittings
E10	Drive belts and jockey pulley
E11	Heat shields
E12	Oil cooler pipes and fittings