

FOUR-DOOR MOTOR CARS 1980-1989

Electrical System Menu

M1	Battery tray, battery and cover, cables and switch, ammeter shunt
M2	Fuseboard fittings and relays
M3	Relays Seat and rear window demister relays
M4	Alternator and regulator Motorola alternator UE 44732 Delco Remy alternator
M5	Alternator mounting Motorola mounting Alternator mounting Delco Remy alternator mounting
Mc1	Automatic air conditioning switches, fan speed module and diode board
Mc2	Automatic air conditioning servo assembly
Mc3	Automatic air conditioning, air temp sensor, sender and circuit breaker
Me1	Starter motor relay Starter motor complete assembly UE 46348 Starter motor complete assembly UE 71223
Me2	Ignition distributor
Me3	Ignition coil ballast resistance, ignition leads and spark plugs
Me4	Ignition amplifier and ignition module
Me5	Electronic control unit and knock sensors
Me6	Electronic control unit fuel injection system engine run sensor
Ms1	Switch box
Ms2	Headlamp and headlamp dip switch RH drive cars Dim dip resistor and relay Headlamp ECU and Fuse
Ms3	LH drive European cars Headlamp and dip relay LH European, Canada and Middle East Headlamps Headlamp and dip switch
Ms4	Front fog lamps and front wing flasher Bosch, fog lamps Integral Hella front fog lamp
Ms5	Front direction indicator and side lamps
Ms6	Rear outboard lamps Rear inboard lamps, stop lamp switch, relay stop lamp failure
Ms7	Interior lights Interior high mounted stop lamp USA only
Ms8	Interior light switches, boot unlock switch
Ms9	Drivers door window lift switches Passengers door window lift switches
Ms10	Windscreen wiper mechanism and switches
Ms11	Windscreen washer and control box intermittent wipe and washer level amplifier Combined windscreen and headlamp wash and control box
Ms12	Headlamp wiper mechanism
Ms13	Headlamp washing Headlamp power wash and timing relay Headlamp power wash (Rolls-Royce)

FOUR-DOOR MOTOR CARS 1980-1989

Ms13	Headlamp power wash (Bentley)
Ms14	Front and rear door solenoid
Ms15	Seat and mirror switches, rear electric window lift inhibit switch
Ms16	Steering column switches
Ms17	Aerial, speakers, radio balance control Hirschmann aerial, speakers, radio balance control and filter Merlin aerial Rear mounted aerial and power amplifier
Ms18	Horns
Ms19	Instrument and warning light cluster Warning lights centre console switches and cigar lighter Instrument
Ms20	Seat switches and memory switch centre console
Ms21	Lower facia panel switches Centre division console and switches
Ms22	Petrol filler door solenoid and switch
Ms23	Cigar lighter
Ms24	Automatic speed control Vacuum pump solenoid valve and mounting
Ms25	Passive restraint motor ECU and warning lights
Ms26	Rear window demist timer
Ms27	Elapsed mileage indicator Single catalyst monitor 100 kph speed warning device cars for Japan 120 kph over speed warning device
Ms28	Fuel pump ballast resistor
Ms29	Cooling fan delay timer boost limit control unit. spark control unit (ECU)
Ms30	Cellular telephone and fittings
Ms31	ABS ECU wheel sensors and relay (where fitted)
Ms32	Miscellaneous electrical items
Ms33	Interior high mounted stop lamp
Ms34	Terminal and connector accessories
Ms35	Terminal and connector accessories
Ms36	Terminal and connector accessories
Ms37	Assembly looms and link cables
Mt1	Transmission (automatic gearbox), gearbox actuator and loom assembly RH 2797